



JK35-590

When the text becomes difficult to read, stick on a new warning label (nr 110715) where indicated. The tool may not be used without readable label.

När texten blir svårläst, klistra en ny varningsetikett (nr110174) på angiven plats. Verktöget får ej användas utan läsbar etikett.



81



Pos Ref Pos Ref No.	Detalj Part Artikel Référéncé No.	Benämning	Discription	Bezeichnung	Designation	Antal Qty	Ann. Notes
	143049	O-ring sats	O-ring kit	O-ringsatz	Jeu d'Orings	1	
	143069	Reparationsats	Repair kit	Repartursatz	Jeu de rechange	1	
1	946657	Skruv	Screw	Schraube	Vis	4	
2	139486	Topplock	Cap	Platte	Chapeau	1	
3	148034	Packning	Gasket	Dichtung	Garniture inférieur	1	
4	148047	Kompressionsbricka	Compression Washer	Druckscheibe	Rondelle de compr.	1	
5	132322	Lock för cyl.foder	Cylinder cap	Zylinderkappe	Chapeau de cylindre	1	
6	148040	Tätningring	Seal	Ring	Garniture	1	
7	972110	Glidring	Glide ring	Gleitring	Bague	2	
8	972119	O-ring	O-ring	O-ring	Joint torique	2	
9	191143	Kolv	Piston	Kolben	Piston	1	
10	145117	Drivhållarpinne	Driver pin	Stift	Axe d'enfonceur	1	
11	149088	Kolvdämpare övre	Upper bumper	Bodenplatte	Butée	1	
12	164116	Drivare	Driver blade	Stösselblech	Lame d'enfonceur	1	
13	134266	Kolv kompl. m. driv.	Piston with driver	Kolben kpl	Piston enf. compl.	1	
14	190159	Cylinderfoder	Cylinder	Zylinder	Cylindre	1	
15	972115	O-ring	O-ring	O-ring	Joint torique	1	
16	148035	Tätningring backventil	Seal for back valve	Ventilring	Garniture de valve	1	
17	149087	Kolvdämpare nedre	Lower bumper	Bodenplatte	Butée	1	
18	150295	Hylsa	Cage	Hülse	Cage	1	
19	972118	O-ring	O-ring	O-ring	Joint torique	1	
20	972117	"	"	"	"	1	
21	150294	Mellanring	Cylinder ring	Zylinderring	Bague centrale	1	
22	972116	O-ring	O-ring	O-ring	Joint torique	1	
23	972114	"	"	"	"	2	
24	147093	Bottenbricka	Bottom washer	Scheibe	Rondelle	1	
25	148033	Packning	Gasket	Dichtung	Garniture inférieur	1	
26	972058	O-ring	O-ring	O-ring	Joint torique	1	
27	179058	Anslutningslock	Cap	Abschlussdeck	Couvercle	1	
28	946512	Skruv	Screw	Schraube	Vis	2	
29	971003	Ljuddämpare	Sound absorber	Schalldämpfer	Silencieux	1	
30	987026	Insticksnippel	Nippel	Stecknippel	Raccord	1	
31	946699	Skruv	Screw	Schraube	Vis	4	
32	162694	Främre drivarstyrning	Front nozzle plate	Abdeckplatte	Plaque avant	1	
33	162774	Bakre drivarstyrning	Rear nozzle plate	Führungsplatte	Plaque arrière	1	
34	946511	Skruv	Screw	Schraube	Vis	2	
35	165083	Inre avtryckare	Inner trigger	Innen hebel	Intérieur détente	1	
36	951042	Spärring	Reteiner	Seegerring	Frein daxes Seeger	2	
37	145119	Pinne inre avtryckare	Pin	Stift	Goupille	1	
38	165084	Avtryckare	Trigger	Ventilhebel	D'etente	1	
39	945039	Spännstift	Tension pin	Stift	Goupille de tension	1	
40	162769	Dörr	Door	Vorderplatte	Porte	1	
41	946657	Skruv	Screw	Schraube	Vis	1	
43	173126	Fjäder	Spring	Feder	Ressort	1	
45	134259	Säkerhetsbygel	Safety	Auslösesperre	Étrier de sûreté	1	
46	147090	Distansbricka	Spacer	Distanzscheibe	Rondelle d'écartement	1	
47	147089	Styrbricka	Guidance	Führungsscheibe	Dessour	1	
48	946687	Skruv	Screw	Schraube	Vis	1	
49	972030	O-ring	O-ring	O-ring	Joint torique	1	
50	972039	"	"	"	"	1	
51	191084	Ventilhylsa	Valve cage	Ventilkolben	Cage de valve	1	
52	173066	Fjäder	Spring	Ventilfeder	Ressort	1	
53	972121	O-ring	O-ring	O-ring	Joint torique	2	
54	191153	Ventilspindel	Valve stem	Ventilkolben	Cage de valve	1	
55	146102	Mutter	Nut	Mutter	Ecrou	1	
56	156946	Fjäderhus	Springhouse	Federhaus	Ressort de chargement	1	
57	174057	Frammatarfjäder	Feeder spring	Zugfeder	Ressort de poussoir	1	
58	150291	Fjädercentrum	Spring center	Federrolle	Ressort central	1	
59	145134	Axel för fjäderrulle	Schaft for springroller	Stift	Aigville	1	
60	946702	Skruv	Screw	Schraube	Vis	1	
61	161247	Frammatare	Pusher	Kolben	Poussoir	1	
62	174058	Fjäder	Spring	Feder	Ressort	1	
63	135145	Fäste laddn.lucka	Cover holder	Endabdeckung	Support	1	
65	134194	Laddningslucka	Cover	Abdeckung	Porte de chargement	1	
66	134263	Täckplåt	Staple shield	Abdeckschiene	Protecteur en tôle	1	
67	946663	Skruv	Screw	Schraube	Vis	1	
68	160124	Frammatarstopp	Pusherstop	Klobenstopper	Arret de poussoir	1	
69	173052	Låsfjäder	Lock spring	Druckfeder	Ressort de blocage	1	
70	160123	Låskolv	Lock piston	Bolzen	Piston de blocage	1	
71	150311	Spärrhylsa	Lock cage	Verschlusshülse	Cage de blocage	1	
72	162775	Klammerbana	Rail	Klammerträger	Rail	1	
73	146202	Plattjärsmutter	Nut	Mutter	Ecrou	1	
74	946697	Skruv	Screw	Schraube	Vis	3	
75	146201	Plattjärsmutter	Nut	Mutter	Ecrou	1	
76	146211	Mutter	Nut	Mutter	Ecrou	1	
77	146212	Plattjärsmutter	Nut	Mutter	Ecrou	1	
78	165082	Avtryckare	Trigger	Ventilhebel	Détente	1	
79	134220	Avtryckare kompl	Trigger	Ventilhebel	Détente	1	
80	946700	Skruv	Screw	Schraube	Vis	1	..
81	110174	Varningsskylt	Warning label	Sicherheitsschild	Plaque de sign	1	Swedish
	110175	"	"	"	"	1	English
82	132321	Klammerbana kompl	Rail	Klammerträger	Rail	1	